



DIGITAL PHOTO PRINTER

# DP-DS620 Series

Version 2.0.1.2

## Printer Driver Instruction Manual

Supported OS: Windows 11

- Safety precautions

Before you use the printer, carefully read the User Guide to ensure that you use the printer correctly. Be aware that the content complies with the standards at the time the User Guide section related to safety, including usage and safety precautions, was created.

- Modifications

For product safety, it is prohibited to modify the DP-DS620 Series printer, DP-DS620 Series printer driver, and CD contents.

- Copyright

The copyrights, trademark rights, and other intellectual property rights related to documents and programs included with this product are the property of Dai Nippon Printing Co., Ltd. and other rights holders. You cannot copy and use these items without the permission of Dai Nippon printing Co., Ltd. except where permitted by applicable laws.

Microsoft and Windows are trademarks or registered trademarks of Microsoft Corporation in the United States and in other countries.

- About the product destination

You cannot resell/use the DP-DS620/DP-DS620 EX without destination number (A) in the U.S.

## ***Table of contents***

---

<b><i>Chapter 1 Installation</i></b>	<b><i>1</i></b>
1.1 Prepare the printer and computer	2
1.2 Install the driver package	4
1.3 Install the printer driver	7
1.4 Install drivers for unspecified devices	8
<b><i>Chapter 2 Properties</i></b>	<b><i>10</i></b>
2.1 Open the printer properties	10
2.2 Print settings functions	12
2.2.1 Layout	12
2.2.2 Advanced options	13
2.2.3 Paper/Quality	19
2.2.4 Option	19
2.2.5 Color Adjustment	21
2.2.6 Printer information	22
2.3 Default values for settings	24
2.4 Color management	25
2.5 Print Area	26
2.6 Orientation	27
<b><i>Chapter 3 Update the driver</i></b>	<b><i>28</i></b>
<b><i>Chapter 4 Delete the driver</i></b>	<b><i>35</i></b>


# Chapter 1 Installation

## Installation procedure

The installation procedure is made up of three steps.  
The details of each step are explained below.


Step 1 Prepare the printer and computer

→ "1.1 Prepare the printer and computer"




Step 2 Install the driver package

→ "1.2 Install the driver package"



Step 3 Install the printer driver

→ "1.3 Install the printer driver"



**IMPORTANT NOTE:** This DNP Printer driver can **ONLY** be installed on Windows 11 OS. Installing this driver onto older Windows operating systems may cause an installation failure or printing errors.

## 1.1 Prepare the printer and computer

- 1) Make sure that the DP-DS620 printer power is off.  
Prepare a USB cable. However, do not use the USB cable to connect the printer and computer at this time.
- 2) Log in to Windows as an administrator. The following explanation presumes that the operations are carried out with administrator privileges.

**CAUTION:**

The display settings of the computer must be set as follows. If the settings differ from the following, the printing preferences screen and other items may not fit in the display area.

- Resolution: At least 1280x800
- Size of text and other items (DPI): 100%

- 3) Right click "Start", and then select "Installed apps".




Figure 1.1.1 Screen when the Start button is right clicked

**NOTE:** You must **UNINSTALL** the previous DNP printer driver **PRIOR** to installing the DNP v2.x Windows 11 driver, especially when the PC has been upgraded from Windows 10 to Windows 11.

- 4) In the list of apps, check that “Windows Driver Package - Dai Nippon Printing DP-DS620 (mm/dd/yyyy x.x.x.x)” appears. (mm/dd/yyyy is the date, x.x.x.x is the version.)




Figure 1.1.2 Installed apps

- 5) If the driver package appears in the list, delete the printer driver and then carry out installation. For the installation procedure, see “Chapter 3 Update the driver”.  
If the driver package does not appear in the list, carry out installation according to the procedure in “1.2 Install the driver package”.

## 1.2 Install the driver package

Insert the included CD into the disc drive.

Open Windows Explorer, and then click the corresponding drive.

If AutoPlay is enabled, a message appears stating “Tap to choose what happens with this disk”.

Click the message and select “Open folder to view files Windows Explorer”.

Select the following installation folder. \*Select the folder for your usage environment.

CD drive:\\DP-DS620\_Driver\\11




Figure 1.2.1 Driver Package folder

In the selected folder, double click the following file: DriverInstall.CMD. (Depending on your usage environment, the .CMD extension may not be displayed.)




Figure 1.2.2 Installation file

When a User Account Control dialog box appears, click “Yes”.




Figure 1.2.3 User Account Control

The Welcome to the Device Driver Installation Wizard! screen appears. Click “Next >”.




Figure 1.2.4 Start of Installation Wizard

Click “Install” when the Windows Security confirmation display appears.




Figure 1.2.5 Windows Security confirmation

Installation of the driver package starts. Wait until installation finishes. The “Completing the Device Driver Installation Wizard” screen appears. Click “Finish”.




Figure 1.2.6 Finish of Installation Wizard

## 1.3 Install the printer driver

Use the USB cable to connect the printer and computer, and then switch on the power of the printer. After the printer is recognized, installation of the driver starts.

\*For the connection, see the User Guide of the printer.

Click “Start”, select “Settings” -> “Bluetooth & devices”, and then open “Printers & scanners”.




Figure 1.3.1 Bluetooth & devices

On the Printers & scanners screen, check that DP-DS620 appears. This completes installation of the DP-DS620 printer driver.




Figure 1.3.2 Printers & scanners

After the installation of the printer driver is complete, always restart the computer.

## 1.4 Install drivers for unspecified devices

If the printer does not appear on the Printers & scanners screen, select “Devices” on the “Bluetooth & devices” screen. Select “More devices and printer settings” on the “Devices” screen to open the “Devices and printers” screen. If you connect a printer that is on to the computer before installing the driver package, a device is created under “Unspecified” in “Devices and printers”.




Figure 1.4.1 Photo Printer

In such a case, use the following method to install the printer driver. Furthermore, use the following method to install the printer driver if you use the standard installation procedure (install the driver package, connect the printer, and then install the printer driver), but the driver is not installed correctly, and a device is created under “Unspecified”.

### 1. Install the driver package

When the driver package has not yet been installed, install it by following the procedure in “1.2 Install the driver package”.

If you install the driver package, installation of the printer driver for the unspecified device completes it automatically.

### 2. Installing a driver for an unspecified device

Refer to page 9 for the driver installation procedure for an “Unspecified” device after installing the driver package.

1. Right-click “Dai Nippon Printing DP-DS620” of the “Unspecified” device in “Devices and Printers”, and click “Remove device” from the pull-down menu.




Figure 1.4.2 Delete “Photo Printer”

2. Disconnect the USB cable connected to the printer.
3. Restart your computer.
4. After starting up the computer, connect the USB cable again and turn on the printer.

In Printers & scanners, make sure that DP-DS620 is present.  
This completes installation of the printer driver.




Figure 1.4.3 Printers & scanners


After the installation of the printer driver is complete, always restart the computer.

## Chapter 2 Properties


You can configure various printer settings from the Properties of the driver. Make sure you understand the contents well before changing settings. To use the properties, log in as an administrator. Depending on the application you are using, you must perform this operation from the print settings of the application.

### 2.1 Open the printer properties


1. Click "Start", and then select "Settings" to open the Settings screen.




2. From the "Settings" screen, select "Bluetooth & devices" -> "Printers & scanners".



3. Click “DP-DS620”, and then select “Printer properties” to open the Properties screen.



4. The DP-DS620 Properties screen appears.



## 2.2 Print settings functions

If you select the basic settings from the Properties screen, you can change various print settings.

### 2.2.1 Layout




Figure 2.2.1 Layout tab


#### Orientation

Set the print orientation to “Portrait” or “Landscape”.  
For details, refer to “2.6 Orientation”.

#### Page Order

In the application, specify the order when multiple copies of an image are printed.

Example) Print order



#### Pages per Sheet

Set printing of the specified division size. In most situations, set “1”.

Example) Division size



## 2.2.2 Advanced options

If you select “Advanced...” on the Layout tab, you can configure various advanced options.




Figure 2.2.2.1 Advanced settings




Figure 2.2.2.2 Advanced options tab

### Paper Size

Specify the paper size. The paper size that can be specified depends on the media size that is loaded in the printer. If the printer is offline, the loaded media size is assumed to be 6x4. Also multiple layout will be automatically used depending on the specified paper size. For details, see <Multiple layout> described later.

Loaded media size	Specifiable paper size	Multiple layout
5x3.5(*1)	[5x3.5], PR(3.5x5)	-
6x4(*1,*2)	5x3.5, PR(3.5x5), [6x4], PR(4x6)	-
5x7(*1)	5x3.5, PR(3.5x5) 5x5, [5x7]	Enable Disable
6x8(*1,*2)	5x3.5, PR(3.5x5), 6x4, PR(4x6) 5x5, 5x7, 6x4.5, 6x6, [6x8], PR(4.5x6)	Enable Disable
6x9(*2)	5x3.5, PR(3.5x5), 6x4, PR(4x6), 6x4.5, PR(4.5x6) 5x5, 5x7, 6x6, 6x8, [6x9]	Enable Disable

The paper size in square brackets [ ] is the default paper size for the loaded media.

\*1: Paper sizes that cannot be used for printing are grayed out.

\*2: For paper sizes that can create margins on the sides of the output results, a warning




Figure 2.2.2.3 Incompatibility media size (Gray out indication)




Figure 2.2.2.4 Incompatibility media size (Warning indication)

**Copy Count**

You can specify the number of copies to be published for images.

**Print Quality**

Specify the resolution.

Print quality	Function
<b>High-speed</b>	Print using high speed mode
<b>High-quality</b>	Print using high quality mode

**ICM Method**

ICM Method	Function
<b>ICM Disabled</b>	Synchronized with "Color Adjustment Disabled" in the 2.2.4 Option.
<b>ICM Handled by Host System</b>	Synchronized with "Color Adjustment ICM" in the 2.2.4 Option. Manage colors using the driver.
<b>ICM Handled by Printer</b>	When this item has been selected, operation is the same as "ICM Handled by Host System".

**ICM Intent**

Set the rendering method when using ICM. For the ICC profile, always set to "Pictures".  
Do not use other settings.

**Advanced Printing Features**

Always set "Enabled". Do not use other settings.

**Pages per Sheet Layout**

Set the layout direction of an image when the Pages per Sheet setting is set for multiple divisions.

**Border**

Synchronized with Border in the Option.

**Overcoat Finish**

Set the overcoat finish method for the surface of printed items from the following four types.

Overcoat Finish	Function
<b>Glossy</b>	Create an item with a glossy finish.
<b>Matte</b>	Create an item with a matte finish.
<b>Luster</b>	Create printouts with rough surface and semi-gloss finish that has less glare. (*1)
<b>Fine Matte</b>	Create printouts with fine grain and strong matte finish. (*2)

\*1: Supported by version 01.30 and later.

\*2: Supported by version 01.52 and later.

## Print Re-try

Specify whether to print data in the printer buffer after a printer error has been cleared.

Print Re-try	Function
<b>Disable</b>	Clear the print data in the printer buffer when a printer error occurs. You must send the cleared print data again after the error is cleared. When you use an application with an error recovery function, select this option.
<b>Enable</b>	Save print data in the printer buffer when an error occurs. The printing process is restarted from the saved data after the error is cleared. Note that if the power is switched off, the data is not saved.

Depending on the content of the printer error, it may be necessary to restart the printer to clear the error. In such cases, the print data in the printer buffer is cleared regardless of the Print Re-try setting.

The following section shows the operation for each Print Re-try setting by error.

Error content	When Print Re-try is "Disable"	When Print Re-try is "Enable"
Paper end	You must send the unprinted image data again after the error is cleared.	The printing process is restarted from the data saved in the printer buffer after the error is cleared. When the paper initialization operation is to be carried out, printing occurs afterwards.
Ribbon end		
Cover open		
Paper jam (*1)		
Ribbon error (*1)		
Paper setting error		
Data error	Because the printer must be switched on and off to clear the error, the print data in the printer buffer is cleared regardless of the Print Re-try setting.  After the printer has restarted, you must send the unprinted image data again.	Because the printer must be switched on and off to clear the error, the print data in the printer buffer is cleared by switching the printer off, even when the Print Re-try setting is "Enable".  After the printer has restarted, you must send the unprinted image data again.
Head voltage error		
Head position error		
Power supply fan stopped		
Cutter error		
Head temperature error		
Media temperature error		
RFID module error		
System error		

\*1: After the printer stops due to an error, follow the User Guide of the printer to eliminate the cause of the paper or ribbon error.

## 2inch cut

Specify whether to cut paper into multiple sheets with a 2-inch length when you use a specified paper size.

2inch cut	Function
<b>Disable</b>	Cut at the normal size.
<b>Enable</b>	Cut at 2-inch lengths so that the 6x4 size becomes two sheets and the 6x8 size becomes four sheets.

**< Multiple layout >**

When 5x7, 6x8 or 6x9 media is used, you can use a two-picture layout. You can enable multiple layout settings by setting the paper size of the printer driver. If it sends multiple images from the application, the printer driver allocate them automatically as the multiple layout.

The following section shows the image sizes.

**Layout settings**

Driver paper size setting	Paper direction	Paper size length x height (mm)	Media used
(5x3.5)	Portrait	(131.1x92.1)	5x7, 6x8, 6x9
	Landscape	(92.1x131.1)	
PR (3.5x5)	Portrait	(92.1x131.1)	
	Landscape	(131.1x92.1)	
(6x4)	Portrait	(156.1x105.0)	6x8, 6x9
	Landscape	(105.0x156.1)	
PR (4x6)	Portrait	(105.0x156.1)	
	Landscape	(156.1x105.0)	
(6x4.5)	Portrait	(156.1x117.3)	6x9
	Landscape	(117.3x156.1)	
PR (4.5x6)	Portrait	(117.3x156.1)	
	Landscape	(156.1x117.3)	


Multiple layout is carried out under the following conditions.

1. Set 5x7, 6x8 or 6x9 size media in the printer.
2. Set the paper size of the printer driver to one of the abovementioned paper sizes.
3. From the application, send multiple images.

Note) Depending used conditions, the rewinding print might be carried out instead of the multiple layout. Because they are carried out by the print job, multiple layout are carried out when there are multiple images in a single job.

If you want to layout the same image, send the same number of images as the number-of-sheets setting.

The printer handles two pictures at one time and cuts the paper after it is ejected.











**< Rewind Print function >**

When printing (6x4) size to 6x8 size media, printing is optimized to reduce consumption of the ribbon.

Furthermore, when printing (5x3.5) size to 5x7 size media or when printing (6x4.5) size to 6x9 size media, printing is similarly optimized to reduce consumption of the ribbon.

The above operation applies only to the DP-DS620/DP-DS620 EX. When (6x4) is selected with the DP-DS620 (A)/DP-DS620 EX(A), printing is performed without rewinding the ribbon. The same applies even if (5x3.5) or (6x4.5) is selected.


The following shows the difference in ribbon consumption when the paper size is set to (6x4) for 6x8 sized media.

	DP-DS620/DP-DS620 EX	DP-DS620 (A)/DP-DS620 EX(A)
When printing one sheet at 6x4 size once	 <p>*After printing, the ribbon is rewound and adjusted to the next print position.</p>	
When printing one sheet at 6x4 size twice	 <p>*After the first sheet is printed, the ribbon is rewound, and the second sheet is printed.</p>	
When printing two sheets at 6x4 size once	 <p>*Two sheets are printed at the same time in a multiple layout.</p>	 <p>*Two sheets are printed at the same time in a multiple layout.</p>
When printing one 6x4 size sheet once, and then printing two 6x4 size sheets once	 <p>*After the first sheet is printed, the ribbon is rewound, and the second and following sheets are printed. Furthermore, after the third sheet is printed, the ribbon is rewound and adjusted to the next print position.</p>	 <p>*For the second and third sheets, two sheets are printed at the same time in a multiple layout.</p>


## < Application usage example >

This usage example uses Windows Explorer.


Step 1. In Windows Explorer, select two or more pictures.  
Next, click “Show more options”.




Step 2. Click “Print”.




Step 3. Select “Fit picture to frame” check box, and then click “Options...”.




Step 4. Click “Printer Properties...”.




Step 5. Set the Orientation to “Portrait”, and click “Advanced...”.



Step 6. Set the paper size to the setting of the multiple layout. Click “OK” twice to close the dialog boxes in Step 6 and 5 and return to the display in Step 3.



Step 7. Click the “Print” button.



## 2.2.3 Paper/Quality




Figure 2.2.3 Paper/Quality tab

### Color

Set Color. Do not use black and white.

## 2.2.4 Option




Fig 2.2.4.1 Option tab




Fig 2.2.4.2 Sharpness setting

### Border

Specify a border for printing. (Select the check box for a border.) Synchronized with Border Enable/Disable in the Advanced settings.

### Sharpness

Process sharpness using one of the 11 stages (Figure 2.2.4.2). If the setting is 0 (Default), sharpness is not processed. Moving to the minus (-) side blurs the image and moving to the plus (+) side sharpens the image.

## Color Adjustment

### None

Synchronized with the ICM Method in the Advanced settings. If this check box is selected, ICM is disabled, the Color adjustment tab is also disabled, and the printer driver does not carry out color adjustment.

### Handled by Driver

If this check box is selected, ICM is disabled, and the 2.2.5 Color Adjustment is enabled. The result is applied to the adjustment values of the following items: Gamma, Brightness, Contrast, and Chroma.

### ICM

Synchronized with the ICM Method of the Advanced settings (ICM Handled by Host System). If this check box is selected, the driver manages colors.

### ICM & Driver

If this check box is selected, ICM (color management) and the 2.2.5 Color Adjustment are enabled.

## Language

Change the display language for the following items: "Option", "Color Adjustment" and "Printer Info". The selected language is enabled the next time the print settings are displayed.

### [Available languages]

- Japanese
  - English (US)
  - French (France)
  - German (Germany)
  - Russian (Russia)
  - Spanish (Spain)
  - Korean
  - Chinese (People's Republic of China)
  - Chinese (Taiwan)
- When your operating system environment corresponds with one of the above settings, the default display language is the language of the corresponding country. Furthermore, when your operating system environment does not correspond with one of the above settings, the default display language is English.
  - To use a language different from that of your operating system, you must install the following font for the corresponding language.

Language	Font
Japanese	Yu Gothic UI
English (US)	Segoe UI
French (France)	Segoe UI
German (Germany)	Segoe UI
Russian (Russia)	Segoe UI
Spanish (Spain)	Segoe UI
Korean	Malgun Gothic
Chinese (People's Republic of China)	Microsoft YaHei
Chinese (Taiwan)	Microsoft JhengHei

## About

Show the driver version.

### 2.2.5 Color Adjustment

If the Handled by Driver check box is selected in the 2.2.4 Option, the adjustment values of the Color Adjustment tab are applied to the image.




Fig 2.2.5 Color Adjustment tab

The following section shows the setting ranges on the Color Adjustment tab.

Adjustment item	Adjustment value
<b>Gamma</b>	-100 (dark) to 100 (bright) ("0" results in no adjustment, γ2.0 to 0.5) Adjust the density of the half-tone section of the image. Increasing the gamma value brightens the half-tone section. Sync check box ON: Set RGB to same value. OFF: Set RGB to different value.
<b>Brightness</b>	-100 (dark) to 100 (bright) ("0" results in no adjustment) Adjust the brightness of the image. Increasing the brightness value brightens the entire image. Sync check box ON: Set RGB to same value. OFF: Set RGB to different value.
<b>Contrast</b>	-100 (weak) to 100 (strong) ("0" results in no adjustment) Adjust the contrast of the image. Increasing the contrast value increases the difference of brightness and darkness. Sync check box ON: Set RGB to same value. OFF: Set RGB to different value.
<b>Chroma</b>	-100 (weak) to 100 (strong) ("0" results in no adjustment) Adjust the chroma of the image.

## 2.2.6 Printer information

View the printer information.




Fig 2.2.6.1 Printer Information tab















Figure 2.2.6.2 Display when incorrect media is loaded

The following section shows the information displayed in the Printer Info tab.

Display item	Display details		
Media Info	This area shows the type, the size and remaining number of printable sheets for the ribbon media and the paper type in the printer. * Media information is not displayed when a media type not supported by the printer has been loaded. (Figure 2.2.6.2)		
Printer Status	Displays the status of the printer using icons and characters.		
	Display icon (Color)	Display characters	Status/Response
	 (Green)	Waiting	Printing is possible.
	 (Blue)	Printing	The printer is printing.
	 (Yellow)	Door open	Front door is open. Close the front door.
	 (Yellow)	Ribbon end	No ribbon remains. Load new media. (Replace the paper and ribbon as a set.)
	 (Yellow)	Paper end	No paper remains. Load new media. (Replace the paper and ribbon as a set.)

Display item	Display details		
Printer Status	Display icon (Color)	Display characters	Status/Response
	 (Gray)	Offline	The printer cannot be recognized. Connect the printer and computer, and then turn on the power.
	 (Purple)	Cooling head	The head is being cooled. Please wait a while. Printing will resume automatically.
	 (Orange)	Ribbon error	The ribbon is not set correctly. Reload the ribbon properly.
	 (Orange)	Paper size setting error	The printer settings and size of the installed ribbon do not match. Check the paper size setting and ribbon size.
	 (Orange)	Paper jam	A paper jam was detected. Remove the paper and reload it properly.
	 (Red)	System error	System error. Restart the printer and computer. If the printer does not recover after the restart, contact the service center.
* A warning message is displayed when a media type not supported by the printer has been loaded.(Figure 2.2.6.2)			
Total Count	Total count of printed sheets (printing other than 6x4.5, 6x4 or 5x3.5 size will count as two sheets).		
Firmware Version	Version of the control program of the printer. xx.xx indicates the version. <ul style="list-style-type: none"> <li>DS620A xx.xx (For the United States)</li> <li>DS620 xx.xx (For other countries)</li> </ul>		
Serial No.	Serial number of the printer.		
Color Control Data	Printer color control data.		

## 2.3 Default values for settings

The following section shows the default values of the settings (at installation). If the settings have been changed, and the printer driver no longer operates normally, return to the default values shown below.

Note) Depending on the service pack of your operating system or your usage environment, the default values at installation may differ from those in the chart below.

Chart 2.3 Default print settings

Chart 2.6 Default Print Settings

Tab	Setting			Value	
Layout	Orientation			Portrait	
	Page Order			Front to Back	
	Pages Per Sheet			1	
Paper/Quality	Color			Color	
Option	Border			Disable	
	Sharpness			0 (Default)	
	Color Adjustment			ICM	
	Language setting			English	
Color Adjustment	Gamma			0	
	Brightness			0	
	Contrast			0	
	Chroma			0	
Advanced settings (In the Layout tab, click “Advanced...”)	Paper/Output	Paper Size		Depends on printer media size (*1)	
		Copy Count			1 Copy
	Graphic	Print Quality		High-speed	
		Image Color Management	ICM Method		ICM Handled by Host System
			ICM Intent		
	Document options	Advanced Printing Features		Enabled	
		Pages per Sheet Layout		Right then Down	
		Printer function	Border		Disable
			Overcoat Finish		Glossy
			Print Re-try		Enable
2inch cut			Disable		

\*1: For the initial values of paper sizes, see "2.2.2 Advanced options".

## 2.4 Color management

Use Color management to specify the color profile. The installer associates “SD\_DS620-xxxx.icc” and “PD\_DS620-xxxx.icc” by default.

This printer driver automatically changes the printer color profile in accordance with the media that is loaded in the printer.

To use an ICC profile other than the default profile, overwrite the ICC profile that has been registered as the default.

For the ICC profile to overwrite, add the prefix “SD\_” to the profile name for Digital media and the prefix “PD\_” to the profile name for Premium Digital media and Luxury media.

Example: Overwritten profile name

- For Digital : SD\_xxxxxxxx.icc
- For Premium Digital , Luxury : PD\_xxxxxxxx.icc

**Step 1.** From the Printer Properties, select the Color Management tab, and then click “Color Management...”.




Fig 2.4.1 Color Management Tab

**Step 2.** From Device, select DP-DS620.




Fig 2.4.2 Color Management Window

## 2.5 Print Area

The following section shows the image sizes and numbers of dots generated by the paper size setting of the driver.



























Paper size	Orientation	Image size (width x height)		Number of image dots (width x height)	
		(inch)	(mm)	High-speed (300x300 dpi)	High-quality (600x600 dpi)*1
(5x3.5)	Portrait	5"x 3.5"	131.1 x 92.1	1548 x 1088	3096 x 2176
	Landscape	3.5"x 5"	92.1 x 131.1	1088 x 1548	2176 x 3096
(5x5)	Portrait	5"x 5"	131.1 x 130.4	1548 x 1540	3096 x 3080
	Landscape	5"x 5"	130.4 x 131.1	1540 x 1548	3080 x 3096
(5x7)	Portrait	5"x 7"	131.1 x 181.0	1548 x 2138	3096 x 4276
	Landscape	7"x 5"	181.0 x 131.1	2138 x 1548	4276 x 3096
(6x4)	Portrait	6"x 4"	156.1 x 105.0	1844 x 1240	3688 x 2480
	Landscape	4"x 6"	105.0 x 156.1	1240 x 1844	2480 x 3688
(6x4.5)	Portrait	6"x 4.5"	156.1 x 117.3	1844 x 1386	3688 x 2772
	Landscape	4.5"x 6"	117.3 x 156.1	1386 x 1844	2772 x 3688
(6x6)	Portrait	6"x 6"	156.1 x 155.4	1844 x 1836	3688 x 3672
	Landscape	6"x 6"	155.4 x 156.1	1836 x 1844	3672 x 3688
(6x8)	Portrait	6"x 8"	156.1 x 206.2	1844 x 2436	3688 x 4872
	Landscape	8"x 6"	206.2 x 156.1	2436 x 1844	4872 x 3688
(6x9)	Portrait	6"x 9"	156.1 x 232.0	1844 x 2740	3688 x 5480
	Landscape	9"x 6"	232.0 x 156.1	2740 x 1844	5480 x 3688
PR (3.5x5)	Portrait	3.5"x 5"	92.1 x 131.1	1088 x 1548	2176 x 3096
	Landscape	5"x 3.5"	131.1 x 92.1	1548 x 1088	3096 x 2176
PR (4x6)	Portrait	4"x 6"	105.0 x 156.1	1240 x 1844	2480 x 3688
	Landscape	6"x 4"	156.1 x 105.0	1844 x 1240	3688 x 2480
PR (4.5x6)	Portrait	4.5"x 6"	117.3 x 156.1	1386 x 1844	2772 x 3688
	Landscape	6"x 4.5"	156.1 x 117.3	1844 x 1386	3688 x 2772

\*1: Convert to 300 x 600 dpi size within the driver, and then send to the printer.

## 2.6 Orientation

The following chart shows the relationship of images generated by an application and printed items (output direction) according to the orientation setting.

**Hint:** The PR print size (center column) is prepared for applications that are not able to change from landscape to portrait and back using the orientation setting on the layout tab. Normally it is recommended to use the non-PR print sizes and use the orientation settings for landscape and portrait on the layout tab.

Original image	Orientation	Driver setting					
		Paper setting					
		(5x3.5) (5x5) (6x4) (6x4.5) (6x6)		PR (3.5x5) PR (4x6) PR (4.5x6)		(5x7) (6x8) (6x9)	
		Generated image	Printed item (Output orientation ↓)	Generated image	Printed item (Output orientation ↓)	Generated image	Printed item (Output orientation ↓)
	Portrait						
	Landscape						
	Portrait						
	Landscape						

## Chapter 3 Update the driver

As when performing the installation, log in as an administrator before carrying out this operation.

### 1. Delete the driver

- 1) Before deleting the printer driver, close all applications. Furthermore, click on the printer to be deleted on the “Printers & scanners” screen, and then click “Open print queue”. Confirm that there are no print jobs, and then start deletion of the driver.




Figure 3.1 Screen when Open print queue is clicked

- 2) From the “Printers & scanners” screen, select DP-DS620, and then click “Remove”.




Figure 3.2 Screen when DP-DS620 is selected and Remove is clicked

If the printer is on but not connected, the DP-DS620 icon is not displayed. In such cases, use the following procedure to delete the device.

- (i) Right click “Start”, and then select “Device Manager”.




Figure 3.2.i Screen when the Start button is right clicked

- (ii) Click View, and then select “Show hidden devices”.




Figure 3.2.ii Displaying the View menu for hidden devices

- (iii) Under “Printers”, right click “DP-DS620”, and then select “Uninstall device”.




Figure 3.2.iii Displaying the menu to delete DP-DS620

- (iv) At the Uninstall Device screen, click “Uninstall”.




Figure 3.2.iv Uninstall Device screen

3) The printer deletion confirmation dialog box appears. Click “Yes”.




Figure 3.3 Printer deletion confirmation dialog box

4) After removing the DP-DS620 printer, click “Print server properties” in “Printers & scanners”.




Figure 3.4 Screen when Print server properties is clicked on the Printers & scanners screen

- 5) The “Print Server Properties” dialog box appears. Click the “Drivers” tab. From the installed printer driver list, select “DP-DS620”, and then click “Remove...”.




Figure 3.5 Printer Server Properties dialog box

- 6) The “Remove Driver and Package” dialog box appears. Select “Remove driver only.”, and then click “OK”. To delete the driver package, carry out the procedure in the next section, “2. Uninstall the driver package”.




Figure 3.6 Remove Driver And Package dialog box

7) The “Print Server Properties” confirmation dialog box appears. Click “Yes”.




Figure 3.7 Driver deletion confirmation dialog box

If the following message appears, the operating system may be using the driver (Print Spooler service) in the background. Disconnect the USB cable and then restart your computer and try deleting the printer driver again.




Fig 3.7.i Driver in use

8) In the “Print Server Properties” dialog box, confirm that DP-DS620 was deleted, and then click “Close”. After deleting the printer driver, uninstall the driver package.




Figure 3.8 Print Server Properties

## 2. Uninstall the driver package

1) Right click "Start", and then select "Installed apps".



Figure 3.9 Screen when the Start button is right clicked

2) Click the menu display button of "Windows Driver Package - Dai Nippon Printing DP-DS620 (mm/dd/yyyy x.x.x.x)" in the list of apps, and then select "Uninstall".




Figure 3.10 Uninstall a program

When the “This app and its related info will be uninstalled.” message appears, click “Uninstall”.




Figure 3.11 Uninstallation confirmation screen

If the User Account Control dialog box appears, click “Yes”.




Figure 3.12 User Account Control

- 3) The “Uninstall Driver Package” screen appears. Click “Yes”.  
 The program has been uninstalled.  
 After uninstalling the printer package, restart the computer.




Figure 3.13 Uninstallation confirmation

### 3. Install an upgrade for the printer driver

After deleting the printer and the printer driver, install the new printer driver. For the installation procedure, see “Chapter 1 Installation”.

### 4. Restart the computer

After the installation of the printer driver is complete, always restart the computer.  
 (Do not print just after installation. Always restart the computer once.)

## Chapter 4 Delete the driver

For the procedure to delete the printer driver, see Chapter 3, “1. Delete the driver” and “2. Uninstall the driver package”.

- MEMO -

**Dai Nippon Printing Co., Ltd.**